


BarSeal



Method

- First ensure hole to be filled is clear of water. (This is beneficial but not essential).
- Remove cartridge from bag
- Remove protective cap.
- Break end seal/plug, this is best achieved with a sharp tap to the end either from a hammer or on the floor.
- With cartridge in the vertical position remove plug and fit nozzle. (retain plug)
- Fit cartridge to applicator gun.
- Insert foam plug into hole to required depth.
- Position nozzle over hole to be filled and slowly squeeze trigger to exude material.
- Fill hole to surface to form a small dome sand or bauxite can be added to produce an anti skid surface.
- Plug and cap can be replaced for secondary application at a later date.

Note

Protective gloves, goggles and overalls should be worn at all times.

See Health and Safety Data Sheet of more information.

Address:

1 Kingdom Avenue, Northacre
Industrial Park, Westbury, Wiltshire
BA13 4WE England

Telephone:

(+44) 01373 858234

Email:

sales@alh-systems.co.uk

Web:

alh-systems.co.uk